

ADAM Internal Cabling




Figure 1: Adam Internal Cabling

ADAM External Cabling




Figure 2: ADAM External Cabling

ADAM Filter-Amp. Board

Beware:
Leave W7,W8 disconnected for normal operation. Used for stand-alone testing: provides continuous auto-zeroing of amp.




Figure 3: Filter-Amplifier Board Layout

