## VCSEL Hygrometer in HIPPO: Performance, calibrations, first results

Minghui Diao, Loayeh Jumbam, and Mark A. Zondlo

Dept. of Civil and Environmental Engineering Center for Mid-Infrared Technologies for Health and the Environment (MIRTHE) Princeton University

Stuart Beaton and Teresa Campos, Earth and Sun Systems Laboratory, NCAR, Boulder, CO NOAA UCATS group (Fred Moore, Dale Hurst, Eric Hinsta, James Elkins) Mark E. Paige, Joel A. Silver, and Steve M. Massick, Southwest Sciences, Inc. START08 Science Team; HIPPO Global Team RAF Technical and Mechanical Crews Zondlo group: David Miller; Amir Kahn; Kang Sun



NASA Earth System Science Fellowship NSF – 0840732 NSF MIRTHE ERC Princeton University

Funding

2010-May-25





Photo by Minghui Diao

#### Water vapor calibration methods



Organic slash bath system
 -80 to -10 °C dewpoint
Critical orfice dilution flow
 3 to 3000 ppmv
LAUDA temperature controller
 -90 to 30 °C dewpoint
MBW-373 LX chilled mirror
 -90 to 30 °C dew point

Using multiple, orthogonal methods to calibrate water vapor concentrations at representative temperature, pressure, and mixing ratio conditions

# Intercomparisons between chilled mirror and temperature-bath systems

(flow dry nitrogen over packed ice column in bath, then directly into the MBW-373LX chilled mirror hygrometer)



Two independent measures of frost point, in excellent agreement

e.g. recent results:

temp. controlled bath is at -80.00 C (0.63 ppmv) chilled mirror is at -79.5 C (0.54 ppmv) ....but this takes more than a day to remove outgassing

### **Calibrations of VCSEL hygrometer in temp. bath**



## @pressure from 100 to 700 torr @ Temperature from -80 to 30°C





## **Climatologies of ISSRs**

**Ice supersaturations (ISS):** 1s; RHi > 100 %.

Ice supersaturated regions (ISSRs):

-/+ 1s RHi < 100 %; Inside RHi > 100 % for many seconds.





- *d***RHi** = RHi<sub>inside</sub> RHi<sub>outside</sub>
- $dRHi = d(e^{1}/e_{s}) = (1/e_{s}) de + e d(1/e_{s})$

Explanations:

Part 1. Part 2.

• Part 1: de is from water vapor partial pressure

e = H<sub>2</sub>OMR (ppmv)\* Pressure(Pa)\* 1e-6

• Part2 : d(1/e<sub>s</sub>) is from temperature

 $1/e_s = 1/(exp(9.550426-5723.265/T+3.53068*ln(T)-0.00728332*T))$ (Murphy and Koop)

## START08: Formation of ISSRs





#### Formation mechanism of ISSRs in HIPPO Global #3 (Quicklook data)



moisture dominates over temperature effects when comparing neighboring areas

#### Comparison of START08 and HIPPO-3 data for ice supersaturation



Size distribution of ISSRs in HIPPO Global #3 (Quicklook data)



N ~ 1000 ice supersaturated areas in HIPPO-3 alone

- vertical thicknesses (10s m); horizontal thicknesses (100-1000 km)
- need to distinguish tropics, mid-lat., polar
- different mechanisms in tropics vs. mid-latitudes?



M. Zondlo and M. Diao



M. Zondlo and M. Diao

#### HIPPO Global Campaign # 3

#### water vapor distribution, March, 2010



Can we generalize this zonally and in time? Look at AIRS... M. Zondlo and M. Diao

## HIPPO #1: RF05, Hawaii to Samoa





## HIPPO #1, RF07: Christchurch to 67 S and back

![](_page_14_Picture_1.jpeg)

![](_page_15_Figure_0.jpeg)

11.

![](_page_16_Figure_0.jpeg)

VCSEL and AIRS show better correlation with tighter space/time constraints

#### HIPPO summary for H<sub>2</sub>O/VCSEL:

#### 1. Performance

HIPPO-1 looks good HIPPO-2 had intermittent bias in 5 C to -20 C range (long period etalon); need to remove some data HIPPO-3 noisy in 5 C to -20 C (low signal)

(improvements: dielectric mirrors, sealed lenses)

#### 2. Calibrations

Multiple, orthogonal methods at trop./lower strat. temp. and press. Appears to be very stable between START08, HIPPO 1-3 (when reasonable S/N) Limited amount of time for calibrations in HIPPO (2-3 weeks), so more efforts needed

## Lee supersaturation (fall submission JGR, Diao et al

Ice supersaturated areas differ from adjacent regions largely due to more moisture, not colder temperatures Small sizes (generally < 30 m thick) < 1 km length) HIPPO data consistent with START08 results in terms of size, PDF, magnitude Examine ice supersaturation differences between NH/SH

#### 4. VCSEL and AIRS H2O show very good agreement throughout HIPPO Calibration/validation of AIRS in polar, SH regions (Jumbam et al., 2010, JGR, to be submitted symmer) RH bimodality in deep tropics excellent agreement with AIRS data

5. Meridional / zonal / vertical extent of SPCZ vs. ITCZ using AIRS to provide larger context.